

CONTINUOUS AND PERIODIC SORPTION CRYOCOOLERS FOR 10 K AND BELOW*

S. Bard, L. Wade, and P. Karlmann
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, CA 911 09
(818) 354-4487

SUMMARY

This paper summarizes the current status of sorption cryocooler development for space applications requiring cooling of infrared and submillimeter sensors to 10 K and below. Ground test results and flight test plans for the flight-qualified Brilliant Eyes 10 Kelvin Sorption Cryocooler Experiment (BETSCE), and test results from a small laboratory periodic 10 K sorption cryocooler are presented. These periodic sorption coolers are ideal for applications that require only intermittent operation at 10 K, with quick cooldown capability (under 2 minutes).

For applications that require continuous cooling, several design variations for high-efficiency lightweight sorption cooler systems are described, and performance predictions and important design challenges are discussed. Ground test results from a continuous 25 K cooler planned for use in a long duration airborne balloon experiment are also presented. This 25 K cooler can be used as an upper stage for a continuous 10 K sorption cooler. Similarly, the potential benefits of using a 10 K sorption cooler as an upper stage for a 4 K cooler are also described.

All of the 10 K cooling stages use hydrogen as the refrigerant fluid. Sorbent beds containing metal hydride powders are sequentially heated to thermally compress the hydrogen. The compressed hydrogen is then expanded and liquefied in a Joule-Thomson refrigeration cycle to produce the desired cooling effect. The low pressure hydrogen exhaust gas is then chemically absorbed by a cooled sorbent bed. ZrNi hydride sorbent beds are used to provide the low vacuum pressure ($< 2.6 \times 10^{-4}$ MPa) needed to solidify and cool hydrogen to < 10 K. LaNi_{4.8}Sn_{0.2} hydride sorbent beds are used to achieve the final compression to typical pressures of about 10 MPa. Thermally cycling the sorbent beds between about 290 and 550 K produces an overall compression ratio of over 10⁵, without the use of any moving parts in the compressor.

The status of ongoing reliability physics experiments designed to demonstrate 10 year life capability for these coolers is also summarized. This includes heater and hydride material characterization and life-cycling tests.

In summary, the combination of long-life, negligible vibration, ability to be scaled easily over a wide range of cooling loads, low weight, and high efficiency makes sorption cooling a highly attractive technique for both periodic and continuous cooling of space instrument sensors to 10 K and below. Efficiencies are significantly greater than for Stirling or Pulse Tube coolers at this temperature, and weight/lift time ratios are much lower than for solid hydrogen or liquid helium cryogenic storage systems.

*Research carried out by the Jet Propulsion Laboratory (JPL), California Institute of Technology under contract with the National Aeronautics and Space Administration.