

Precision Clocks Using Superconducting Niobium Cavities*

by

Jeffrey T. Huynh¹, Dr. Wen Jiang², Prof. Nai-Chang Yeh¹,
Donald Strayer³, Mark Lysek³, Nils Asplund¹, and John Gatewood¹

1. Physics Department, Caltech
2. Resident Research Associate of the National Research Council
3. Jet Propulsion Laboratory, Caltech


* Work performed at the Jet Propulsion Laboratory and Caltech under an
ATD grant from NASA's Microgravity Research Division. JPL is supported
by a contract from NASA

INTRODUCTION

- Applications of high-Q cavities: precise time-keeping, planetary navigation, precise measurements of physical constants.
- Low temperature superconductor cavity offers a feasible solution because of its extremely high quality factors (Q's).
- The record Q is of the order of 10^{11} (Turneaure and Viet, 1970).
- Goal: Utilizing modern electronics, we will build a clock with stability on the order of 10^{-17} using cavities with Q of the order of 10^{10} .

Ultra-high Vacuum Annealing

- E-beam heating cavity up to 1900 °C for 12 hours or more in pressure as low as 1×10^{-9} Torr.
- Besides reducing irregularities on cavity surfaces and in the lattice, vacuum annealing will also help drive out H_2 and O_2 from within the niobium lattice.








Figure 2.1. Field patterns for TE_{011} mode.

Quality Factor Characterization

- Use the Microwave Characterization System to find the resonant frequency and measure the Q-value of an annealed cavity.
- The system has resolution of 1 mHz and is capable of measuring Q-values on the order of 10^{10} - 10^{12} .



Refrigeration and Cavity Mounting




Temperature Control

- $(1/f \partial f / \partial T) \sim -10^{-10} \text{ K}^{-1}$ at 2 K. So we need to have temperature stability $\sim 10^{-7} \text{ K}$ to obtain frequency stability $\sim 10^{-17}$.
- High-Resolution Thermometry uses a SQUID magnetometer with resolution of $\sim 10^{-10} \text{ K}$ to obtain stability of $\sim 10^{-9} \text{ K}$.




HIGH RESOLUTION THERMOMETER SYSTEM

all provided laboratory
Customs & Quality of Technology




The Niobium Cavity


- Designed for TE_{011} mode at 14.12 GHz.
- A groove near the welded joint splits the degeneracy between TE and TM modes



Microwave Characterization System




Characterization of Superconducting Cavity



RESULTS

- An anodized cavity gives a Q of 10^7 at 2K.
- A cavity etched in acid and annealed at 1400°C for 12 hours in ultra-high vacuum gives a Q of 10^8 at 1.77 K.
- Will attempt annealing at higher temperatures (near 1800°C) and for longer period of time.



Quantifying Stability

1. In frequency domain, use the spectral density:

$$S_y(f) = \frac{S_v(f)}{v^2}$$

$S_v(f)$: spectral density of frequency fluctuations

$v(t)$: time-dependent instantaneous frequency

f : time-independent Fourier frequency

2. In time domain, use the Allan variance:

$$\sigma_y^2(\tau) = \frac{1}{2} \langle (\bar{y}_2 - \bar{y}_1)^2 \rangle$$

Estimator:

$$\sigma_y^2(\tau, m) = \frac{1}{2(m-1)} \sum_{i=1}^{m-1} (\bar{y}_{i+1} - \bar{y}_i)^2$$

$$y_i = f(t_k + t) - f(t_k) / \tau$$

τ : averaging time

m : number of samples