

Geness

Solar Wind

Sample Return

Solar Nebala

Payload Conster

Concentrator

Silican Calleders Spacecraft

Presented at:

SEARCH FOR ORIGINS

European Geophysical Society XXIV General Assembly The Hague, The Netherlands, 19-23 April 1999

> By: **Chet Sasaki Genesis Project Manager Jet Propulsion Laboratory / NASA**





Presentation Outline

Part 1: Science

Part 2: Payload Features

Part 3: The Mission System



PART 1: Science





Mission Objective

To collect Solar Wind Materials in Order and To Evaluate the Collected Material To Address the Processes Involved in the Origins of the Solar System.

- Place a Spacecraft Outside the Earth's Magnetosphere
- Expose Ultra-Pure Materials (Collectors/Concentrator)
 - Capture solar wind for two years
 - Solar wind ions and elements collected be above the "noise floor" of the collectors ⇒ clean collectors
- Return the Imbedded Solar Wind Samples to Earth
- Analyze the Samples With State-of-the-Art Laboratory Instruments





Why Genesis?

Examples of Major Planetary Science Questions for Which Genesis Will Provide Information

- (1) How Can We Explain the Great Diversity of Planetary Objects?
- (2) What Makes Earth Different From Its Planetary Neighbors?
- (3) What Is the Sun Made Of? Are We Made of the Same Stuff?



Fundamental Hypotheses

- The Diversity in Planetary Objects Is Primarily a Consequence of Conditions, Events and Processes in the Solar Nebula
- The Elemental and Isotopic Compositions of Planetary Materials Are a Fossil Record of the Solar Nebula
- Solar Nebula Models Will Be Verified by Predicting Planetary Material Compositions Starting With a Solar Nebula Composition Based on Genesis Data
- Similarly, Genesis Isotopic Data Will Be Used to Verify Terrestrial Planet Atmospheric Evolution Models
- Solar Isotope Data (Especially O) From Genesis Test Whether
 1-3 AU Materials Are the Same As in the Sun



Science Collection/Measurement

- Measure Elemental & Isotopic Abundances of Solar Wind Ions.
 - Measurement Priorities
 - Accuracies or Precisions Required
- Collect Separate Samples for Each of 3 Solar-Wind Regimes:
 Low Speed, Coronal Hole, and Coronal Mass Ejections
 - Required to Determine Solar Photosphere Composition From Solar Wind
 - Necessitates Monitoring of Solar Wind Type By Spacecraft
- Provide a Reservoir of Solar Matter for Future Analysis
 - Sets Philosophy on Collector Area
 - Requires Long-Term Curation



Prioritized Measurement Objectives

- (1) O isotopes.
- (2) N isotopes in bulk solar wind.
- (3) Noble gas elements and isotopes.
- (4) Noble gas elements and isotopes; regimes.
- (5) C isotopes.
- (6) C isotopes in different solar wind regimes.
- (7) Mg,Ca,Ti,Cr,Ba isotopes.
- (8) Key First Ionization Potential Elements
- (9) Mass 80-100 and 120-140 elemental abundance patterns.
- (10) Survey of solar-terrestrial isotopic differences.
- (11) Noble gas and N, elements and isotopes for higher energy solar particles.
- (12) Li/Be/B elemental and isotopic abundances.
- (13) Radioactive nuclei in the solar wind.
- (14) F abundance.
- (15) Pt-group elemental abundances.
- (16) Key s-process heavy elements.
- (17) Heavy-light element comparisons.
- (18) Solar rare earth elements abundance pattern.
- (19) Comparison of solar and chondritic elemental abundances.





Accuracies/Precision of Measurements

- Elemental Accuracy (2 σ Limits)= $\pm 10\%$ of the Number of Atoms of Each Element per cm² on the Collector Materials
- Isotopic Precision (2 σ Limits On the Relative Number of the Different Isotopes of an Element Compared to a Terrestial Reference Standard)

O, Mg, Ca, Ti, Cr, Ba	<u>+</u> 0.1%
– C	<u>+</u> 0.4%
– N	<u>+</u> 1.0%
 Noble Gases 	<u>+</u> 1.0%
- ⁷⁸ Kr, ¹²⁴ Xe, ¹²⁶ Xe	<u>+</u> 3.0%
Others	<u>+</u> 1.0%





Collector Materials


The Collector Materials Are the "Containers" Which Will Capture and Hold the Solar Wind Samples. Therefore:

- Must Be Pure Enough:
 - Design Goal Is Signal to Noise Ratio > 100
 - Critical Requirement SNR > 10
- Must Be Clean Enough:
 - Surface Contamination < 2 yr Solar Wind Fluence for any element
 - If Some Surface Contamination Does Occur, There Must Be Methods for Removing It Prior to Analysis
- Must Lend Itself to the Desired Analytical Technique
- Different Materials Work Best for Different Elements






Contamination





Start With Clean Collectors

We Can Consistently Meet or Exceed Requirements
 Example Process Control of Si Wafer Surface Contamination







Bulk Purity of Elements*


*Bulk Purity in Collectors, Mostly Based on Silicon



Green = SNR > 100

Blue = SNR > 10

Blank = SNR > 10 expected







Material Selection vs. Measurement Objective

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
MATERIAL																		
Diamond	CD	BD												СХ				
SiC	CD	BD										CL		СХ				
AuOS	С				вх	вх		В			вх						В	
AIOS			CD	CD														
sos					СХ	СХ			D				•					D
Si	BD	BD			D	D	С	CL	CD	L		СХ		В	CL	CL	CL	CD
Sapphire					вх	вх		CL	СХ	L		CL		В	В	СХ	CL	СХ
Ge				t		:		CL	СХ	L					СХ	СХ	CL	СХ
Vitreloy			вх								СХ				-			
Al			BD	BD					BD								:	
Pd on Pt													С					

C = Selected Material D = Documented Purity X = Planned But not yet documented B = Backup L = Objective with List of Elements; Partial Documentation




PART 2: Payload Features

- General Payload Desciption
- Canister and Collector
- Concentrator






The Genesis Spacecraft/SRC/Payload





Components of the Payload






Collector Array Design

- Bulk Solar-Wind Collector Area > 0.6 m²
- Each of 3 Special-Regime Collector Areas > 0.3 m²
- Collector Array Materials Not To Exceed 200° C for Si and 250° C for Other Materials
- Material From Each Array Shall Be Uniquely Identifiable.
 - In Case Material is Dislodged
- Radioactive Nuclei Collectors Exposed in Lid of SRC.




Integrated Canister CAD Model






Integrated Canister Cover Open








Integrated Canister Deployed





Array Assembly Including Partial Collectors








Concentrator Design

- Average Concentration Factor for N and O Shall Be >20.
- Concentrator Target Area >15 cm².
- Concentrator Must Not Introduce ¹⁷O/¹⁶O Errors > 0.1%.
- Concentrator Target Temperature Not To Exceed 250°C.
- S.W. Ions Shall Be Accelerated > 8 kV Before Impacting the Concentrator Target.
- TBD %(Goal of 90%) of Solar Wind Proton Fluence Shall Be Prevented From Reaching Concentrator Target.






Payload Concentrator Assembly









Prototype Concentrator




Interior w/o Top Grids & MCP Mount



Side View w/Top Outer Can Removed



Complete Assembly w/MCP Mount



Side View w/Outer Can Removed






PART 3: The Mission

- Trajectory Design
- Spacecraft
- Sample Return Capsule (SRC)
- Sample Return
- Mission Operations System




How We're Doing Genesis








Flight System Science Config'n - Top






Sample Return Capsule Cross-Section

Althorax and an area and a second





SRC Hardware









Mid-Air Retrieval of SRC

DACS/Drogue Separation




Mid-air Retrieval Successfully Demonstrated







Overview NOMINAL GDS ARCHITECTURE







BACKUP



Solar Wind Properties

- Solar Wind is Essentially Constant Velocity
 - Different masses have different energies and turn-around points.
 This is the source of mass fractionation.
 - Concentrator design now has energy independent focus
 - Simulated in test chamber by changing mirror electrode voltage with mass
- Group Velocity Varies Between 300-800 km/s
 - Mean velocity is ~440 km/s = 1 kev/amu
 - Coronal hole wind is significantly faster than other types
 - Ion monitor data used to optimize operation of H+ rejection grid and mirror point
- Ion Temperature Significant--Causes Spread in Velocity
 - Causes an effective angular distribution as seen by the concentrator
 - Concentrator has wide field of view T





Expected Solar Wind Abundances

Z	Element	Concentration (parts per million wt.)
3	Li	5.3x10 ⁻⁵
4	Ве	8.9x10 ⁻⁷
5	В	3.1x10 ⁻⁵
6	C	5.4x10°
7	N	2.0x10°
8	0	1.7x10 ¹
9	F	7.2x10 ⁻⁴

Concentration of Solar Wind From 2-Yr Fluence Averaged Over Top 0.1 micron in Silicon

• _____.