




ID 30661
CL01-1911



High Density Holographic Memory

Presented to
Int'l Symposium on Optical Memory


Presented by
Tien-Hsin Chao

Jet Propulsion Laboratory
4800 Oak Grove Drive, Pasadena
California, 91109



Objectives and Performance Specifications

- Objectives :
 - **Develop innovative memory technologies to enable large-capacity, high-speed, read/rewrite of image and digital data in a space environment**
 - **Demonstrate key capabilities:**
 - > Ultra High data/image storage capability (1TB)
 - > High-speed random access data transfer (1GB/s)
 - > Radiation-resistance
- Performance Specifications
 - **A compact holographic data storage with 10 GB non-volatile random access memory per cube**
 - **Up to 10 x 10 cubic memory can be stacked into an ordinary memory board size to achieve a storage capacity of 1TB**
 - **Read/rewrite, rad hard, high transfer rate**



Holographic Memory Light Budget



GOAL: Video-rate recording with storage capacity of 10,000 pages of 1,000x1,000 gray-scale images.

List of materials available for this application

	LiNbO ₃ Fe √	LiNbO ₃ Fe, Mn √	LiNbO ₃ Cr, Cu √	Green Polymer *	Red Polymer *	PMMA Polymer √
thickness	no	no	no	yes (3%)	yes (3%)	yes (2%)
shrinkage	488nm	red+UV	red+blue	532nm	630-670nm	488nm
wavelength	yes	no	no	no	no	no
need fixing	large	large	large**	modest	modest	modest
dynamic range	slow	very slow	slow**	very fast	fast	fast
wiring speed	yes	yes	yes	no	no	no
rewritable						

* Thin materials only. Large-scale storage might be problematic with non-mechanical scanners.

** Projected.




For non-volatile storage of 10,000 holograms, the target diffraction efficiencies are,

$$\eta_h = \left(\frac{M / \#}{M} \right)^2$$

	LiNbO ₃ Fe	LiNbO ₃ Fe, Mn	LiNbO ₃ Cr, Cu	Green Polymer	Red Polymer	PMMA Polymer
M/#	10*	10	30**	6	5	5
η_h	2.5×10^{-7}	10^{-6}	10^{-5**}	3.6×10^{-7}	2.5×10^{-7}	2.5×10^{-7}

* The M/# drops approximately by a factor of 2 after thermal fixing in LiNbO₃:Fe.

** Projected value.



Light Budget Estimate

1. Photon-limited readout:


$$N_e = \eta_{tr} \eta_q \frac{\eta_h \eta_{im} P_{in}}{h\nu} \frac{1}{r_{ON} N_p} t_{int}$$

Variable	Definition	Value
Ne	number of signal electrons	~25,000*
η_{tr}	electron transfer efficiency	0.9**
η_q	quantum efficiency	0.9
η_h	hologram diffraction efficiency	From above
η_{im}	efficiency of readout optics	0.9
P_{in}	readout power	?
$h\nu$	power per electron	4.073×10^{-19} J
$r_{ON} N_p$	number of ON pixels	0.5×10^6 ***
t_{int}	integration time	1 sec.

* For binary data, 100 photoelectrons at a pixel are needed for optimal hard thresholding, considering electronic, optical, and holographic noise.

** Worst-case transfer efficiency from CCD to external electronics.

*** Exact number for binary random-bit patterns.



* Projected value **Readout powers for 1-second integration time**

	LiNbO ₃ Fe	LiNbO ₃ Fe, Mn	LiNbO ₃ Cr, Cu	Green Polymer	Red Polymer	PMMA Polymer
P _{in} (mw)	28	7	0.07*	19	28	28

Recording speed

1. recording speed for 10,000 holograms (target diffraction efficiency is 10⁻⁷).


	LiNbO ₃ Fe	LiNbO ₃ Fe, Mn	LiNbO ₃ Cr, Cu	Green Polymer	Red Polymer	PMMA Polymer
Writing energy mJ/cm ²	3	100*	1**	0.1	1	1
Writing intensity mw/cm ²	100	333*	33**	3.3	80	80

* For recording at He-Ne line. Data for blue recording is not available at the moment.

** Projected value.




System Schematic of an Advanced CHDS Architecture




Unique Advantages

- **Very compact**
 - Cubic package with the size of a cigarette box
- **Massive data storage**
 - store up to 10^4 pages of hologram with 10 Gbytes capacity
- **High-speed**
 - current throughput 200 Mbytes/sec achieved with using a LC Beam Steering Device. Could be 10x faster if FLC is used
- **Device/components maturity**
 - Use two single diode lasers that are commercially available at low cost
 - Beam Steering Device is a emerging technology. JPL is actively engaged with BNS in developing the next generation high-speed version




Liquid crystal phased array beam steering device

- Beam steering based on optical phase modulation



Optical phase profile (quantized multiple-level phase grating) repeats every 0-to- 2π ramp w/ a period d which determines the deflection angle θ



Liquid crystal phased array beam steering device

- Diffraction efficiency:

$$\eta = \left(\frac{\sin(\pi/n)}{\pi/n} \right)^2$$

n : number of steps in the phase profile

e.g., $\eta \sim 81\%$ for $n=4$, $\eta \sim 95\%$ for $n=8$

- Deflection angle:

$$\theta = \sin^{-1}(\lambda/d)$$

for the first order diffracted beam

- Number of resolvable angles:

$$M = 2m / n + 1$$



m : pixel number in a subarray

n : minimum phase steps used


e.g., $M = 129$ for $m=512$, $n=8$ with a 1x4096 beam steering device



Photograph of a Liquid Crystal Beam Steering Device




**Surface phase-modulation profile
of a beam steering device**




LabVIEW Based Controller for Beam Steering

- Use LabVIEW to calculate the theoretically correct beam steering profile (i.e. sawtooth wave).
- Optimize the diffractive efficiency and suppress the spurious high orders
- A hardware-in-the-loop routine has been developed to customize the driving voltage for each and every beam deflection angle
- A nonlinear waveform of the driving voltage profile is obtained for good performance




Sawtooth Profile

- The resulting profile (using an input value or N^* of 57):





*The input value is proportional to the number of gratings on the device.



Tangent Profile

- For optimal results, parameters must be chosen such that the entire range of 0-256 is used with 0 and 256 occurring with a consistent period.
- The selected parameters are unique for each angle.






Resulting Diffraction Patterns


- The spurious higher orders of diffraction are nearly eliminated by using the nonlinear voltage driving waveform to the liquid crystal BSSLM

Device Off

Increasing


N





Liquid crystal phased array beam steering device

- Cascaded beam steering architecture:




A total resolvable angles of more than 10,000 can be easily achieved.




Liquid crystal phased array beam steering device

- **Benefits of using LC SLM beam steering devices:**
 - No mechanical moving parts
 - Randomly accessible beam steering
 - Low voltage / power consumption
 - Large aperture operation
 - No need for bulky frequency-compensation optics as in AO based devices




Performance Characteristics of LC Beam Steering Device

- **Number of pixels: 4096 Reflective**
- **VLSI backplane in ceramic PGA carrier**
- **Array size: 7.4 x 7.4 mm**
- **Pixel size: 1 μ m wide by 7.4mm high Pixel pitch: 1.8 μ m**
- **Response time:**
 - 200 frames/sec with Nematic Twist Liquid Crystal
 - 2000 frames/sec with Ferroelectric electric Crystal (under development)



Book-sized Holographic Memory Breadboard

Input Spatial
Light Modulator







LiNbO_3
Photorefractive Crystal

CCD Detector


Photograph of a JPL compact holographic memory breadboard developed
under the sponsorship of NASA ESTO



Holographically Retrieved Grayscale Images - Asteroid Toutatis



**Experimental results showing retrieved holographic images
of a Toutatis Asteroid**



Summary and Future Work

- We have developed (with BNS Inc.) a new liquid crystal beam steering device for high-speed, random access beam steering for angularly multiplexed hologram recording
- We have developed a compact CHDS breadboard and demonstrated grayscale holographic data storage/retrieval
- We will continue to integrated a 2-D angularly multiplexing scheme to achieve > 10,000 page of holograms store per PR cube
- We will also started radiation tests of holographic data stored in a LiNbO_3 PR crystal
- We will also investigated non-volatile hologram storage using 2-wavelength PR crystal